



Motorola Entice w766 Battery Replacement

If you are having an issue with changing your battery follow the steps listed below.

Written By: Aalan Miranda



INTRODUCTION

This is a simple guide to help remove the back casing of the device and the battery.

Step 1 — Battery



- Slide the tab off the back of the device.

Step 2



- Use the tab located at the top of the battery to release the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 12:39:36 AM.